


1. Schematic description of the goods




HANDX Razor


User's manual



2. Removing the cartridge




Insert the handle,
turn it to the right
to safely remove
the cartridge.



3. Safe cartridge installation

Align the direction of the handle and cartridge to securely lock



4. Purchase of consumables

- For safe and comfortable shaving, it is recommended to change the cartridge every two months.
- For best results, shaving foam is recommended.
- To buy a cartridge, shaving foam or other goods, go to the official website

Using

- For a comfortable and safe shaving, you must first wet your face and then start shaving. Do not shave on dry skin.
- During shaving, do not use force, while you must direct the shaver vertically. Do not shave in the horizontal direction.
- The back of the razor cartridge is of an open type design, it is possible to rinse the razor with water. In no case is it recommended that the shaver be struck against solid objects, this may damage the cartridge. When the razor is washed, it must be completely dried.
- The razor cartridge has a special moisturizing tape that activates in the water and prevents the appearance of irritation, reduces the resistance during shaving. It is not recommended to leave the shaver in a damp environment for a long period of time, otherwise the service life of the moistening tape will decrease significantly or it may completely dissolve.